
ERSATZTEILLISTE
OL 600ex / 610ex

M-OSD-10020-11

ERSATZTEILLISTE OL 600ex/610ex

ZEICHNUNG 1: LOWER BASE UNIT




LISTE 1: LOWER BASE UNIT

NR.	BEZEICHNUNG	BESTELL-NR.
1	HOPPING ROLLER SHAFT	3PA4083-6019G1
2	BEARING	4PP4083-6022P2
3	ONE-WAY CLUTCH GEAR	4PB4083-6024P1
4	RESIST ROLLER	3PB4083-6030P1
5	BEARING (RESIST)	4PP4083-6031P1
6-1	TRANSFER ROLLER A	3YB4083-7640P3
6-2	BEARING C	3PP4083-6289P1
6-3	TR GEAR A	3PP4083-6290P1
8	BACK-UP ROLLER	3PB4083-6064P2
9	BIAS SPRING B	4PP4083-7620P1
10	BACK-UP ROLLER BUSHING	4PP4083-6052P1
11	RESET LEVER L	3PP4083-6053P1
12	RESET LEVER R	3PP4083-6054P1
13	SWITCH ARM	4PP4083-6058P1
14	RESET SPRING	4PP4083-6057P1
15	IDLE GEAR	4PP4083-6080P1
16	IDLE GEAR	4PP4083-6081P1
17	SENSOR PLATE (INLET)	4PP4083-6083P1
18	SENSOR PLATE (OUTLET)	4PA4083-6025G1
19	TONER SENSOR (ADHESION)	4PP4083-6086G1
20	DISELECTRIFICATION BAR	4PB4083-3182P3
21-1	PULSE MOTOR A	4PB4076-6150P1
21-2	PULSE MOTOR B	4PB4076-6151P1
22-1	IDLE GEAR D	3PP4076-6145P1
22-2	IDLE GEAR E	3PP4076-6146P1
23	REDUCTION GEAR C	3PP4076-6147P1
24	FUSING UNIT ASSY, 120V	2YX4083-6100G5
24	FUSING UNIT ASSY, 230V	2YX4083-6100G6
25	EJECT ROLLER ASSY	2PA4083-6120G2
26	MANUAL FEED GUIDE ASSY	2PA4083-6130G1
27	STACKER COVER ASSY	2PA4083-6160G4
28	IMAGE DRUM CARTRIDGE	O P T I O N
29	TONER CARTRIDGE	O P T I O N
30	LED HEAD	3YX4083-6245G3
31	LOWER BASE	2PP4083-6801G2
32	DUMPER ARM (CAULKING)	4PP4083-6191G1

NR.	BEZEICHNUNG	BESTELL-NR.
33	DUMPER	4PB4083-6197P1
34	FLEXIBLE CABLE (LED HEAD)	4YX4121-1025G2
35	WASHER B	4PP4120-1209P1
36	WASHER C	4PP4120-1210P1


ZEICHNUNG 2: UPPER COVER UNIT



LISTE 2: UPPER COVER UNIT

NR.	BEZEICHNUNG	BESTELL-NR.	BEMERKUNG
1-1	UPPER COVER	2PP4083-6808G1	600ex
1-2	UPPER COVER	2PP4083-6808G2	610ex
1-3	UPPER COVER ASSY	2PA4094-7812G5	
2	STACKER	1PP4094-7814P1	
3	STACKER CLAMP	3PP4094-7816P1	
4	GUIDE WIRE	4PB3517-1567P1	
5	LEAF SPRING	3PP3517-1601P1	
6	LENS COVER	2PP4128-1171P1	
7	LENS FRAME	3PP4128-1172P1	
8-5	LOGO FRAME	1PP4128-1246P3	600ex
8-7	OP. PANEL ASSY	2YX4083-6170G32	610ex


ZEICHNUNG 3: BASE UNIT



LISTE 3: BASE UNIT

NR.	BEZEICHNUNG	BESTELL-NR.	BEMERKUNG
1	BASE PLATE	2PP4083-6809G1	
2	CASSETTE GUIDE, L	3PP4083-6802G1	
3	CASSETTE GUIDE, R	3PP4083-6803G1	
4	EJECT SPRING	4PP4083-6152P1	
5	SENSOR PLATE (PAPER SUPPLY)	4PP4083-6082P1	
6	INSULATOR	3PB4083-6144P1	
7	LQ5C PCB (MAIN CONTROL PCB)	4YA4046-1670G12	600ex
	LQ6C PCB (MAIN CONTROL PCB)	4YA4046-1671G11	610ex
8	POWER SUPPLY 120V	4YA4049-7101G1	
8	POWER SUPPLY 230V	4YA4049-7101G2	
9	TRANSFORMER 120V	4YB4049-7032P3	
9	TRANSFORMER 230V	4YB4049-7033P3	
10	FAN MOTOR	4PB4076-6152P1	
11	CONTACT ASSY	3PA4083-6090G1	
13	CASSETTE DETECTRON LEVER	3PP4083-6154P1	
14	PAPER CASSETTE	4YA4083-6260G3	
15	SUPPORT SPRING	4PP4083-6153P1	
16	INLET HOLDER	4PP4083-6145P1	
18	GROUND PLATE	4PP4083-6137P1	
19	LQME-PCB (RAM BOARD)	4YA4121-1058G11	
20	SUMI CARD ASSY (OP. PANEL)	4YX4121-1035G2	
21	LQ8A PCB (PS CONTROL)	4YA4046-1672G11	
22	SEPARATOR ASSY	40259701	


ZEICHNUNG 4: 2ND PAPERTRAY



LISTE 4: 2ND PAPERTRAY

NR.	BEZEICHNUNG	BESTELL-NR.
1	HOPPING ROLLER SHAFT ASSY	3PA4083-6019G1
2	ONE-WAY CLUTCH GEAR	4PB4083-6024P1
3	STEPPING MOTOR	4PB4083-6075P1
4	OLEV-2 PCB	4YA4121-1014G12
5	UNIVERSAL CASSETTE	1PA4083-5640G1
6	CONNECTOR CABLE	3YS4011-3140P1
7	TAPPING SCREW	4PB4083-5670P2
8	S-TIGHT TAPPING SCREW	4PB4013-3100P6
9	MOTOR BRACKET	3PP4083-5617G1
10	IDLE GEAR	4PP4083-5622P1
11	IDLE GEAR (C)	4PP4083-2280P1
12	PAPER END SENSOR LEVER	2PP4083-5636P1
13	BEARING	4PP4083-6022P2
14	HOPPING ROLLER FRAME	1PP4083-5605P1
15	SPRING	4PB4083-5665P1
16	SEPARATION FRAME ASSY	3PP4083-5663G1
17	SEPARATION SPRING	4PP4083-6209P1
18	ANTI VIBRATION SPRING	4PP4083-6228P1


ZEICHNUNG 5: 2ND PAPERTRAY DETAIL A



LISTE 5: 2ND PAPERTRAY DETAIL A

NR.	BEZEICHNUNG	BESTELL-NR.
1	REAR SUPPORT FRAME	1PP4083-5637P1
2	TAPPING SCREW	4PB4083-5670P2
3	RIGHT SIDE FRAME	1PP4083-5611P1
4	SENSOR LEVER	3PP4083-5615P1
5	SLIDE CAM (R)	3PP4083-5613P1
6	CASSETTE SENSOR LEVER	4PP4083-5655P1
7	E-RING	RE2-SK
8	E-RING	RE5-SK
9	LOCK ARM	4PP4083-5623G1
10	SUPPORT SPRING (R)	4PB4083-5660P1
11	PLATE UP LEVER (R)	4PP4083-5612G1
12	E-RING	RE7-SK
13	SHEET GUIDE (U)	1PP4083-5653P1
14	PLATE UP SPRING	4PB4083-5614P1
15	SUPPORT SPRING (L)	4PB4083-5661P1
16	SLIDE CAM (L)	3PP4083-5633P1
17	PLATE UP LEVER (L)	4PP4083-5632G1
18	LEFT SIDE FRAME	1PP4083-5631P1
19	SHEET GUIDE (L)	1PP4083-5654P1
20	LOCK LEVER	1PP4083-5606P1
21	FRONT COVER	1PP4083-5603P1
22	BIAS ROLLER	4PP4083-5609P1
23	BIAS SPRING	4PP4083-5608P1

ZEICHNUNG 6: MULTI FEEDER (UNIVERSALEINZUG)



LISTE 6: MULTI FEEDER

NR.	BEZEICHNUNG	BESTELL-NR.
1	ROLLER A	3PB4083-5514P1
2	PLANET GEAR	4PP4083-5520P1
3	LINK	3PP4083-5540P1
4	SEPARATOR	4PP4083-5544G1
5	STEPPING MOTOR	4PB4083-6075P1
6	OLEV PCB	4YA4121-1014G11
7	CONNECTOR CABLE	3YS4011-3141P1
8	ROLLER B	3PB4083-5524P1
9	SEPARATOR ASSY (ENTHÄLT NR. 4)	3PA4083-5549G1